# **Quick Guide 7057i/8057i**

### Sending

1 Place the originals on the platen or in the optional document processor.



- 2 Press **SEND** on the Home screen.
- 3 Enter the destination address.



#### From the address book:

Press ADDRESS BOOK. Press the checkbox to select the desired destination from the list. Press **SEARCH (NAME)** to find the destination. Enter the name you search for. Confirm with **o**K.


You may choose multiple destinations.

### Enter an e-mail address:

Press E-MAIL ADDR. ENTRY and E-MAIL ADDRESS. Enter the E-Mail address on the touch screen. After that press **OK**.

If you want to send the e-mail to several destinations, go back to step 3.

**4** To send the e-mail press **START**.



### Scan settings



1 Press SEND on the Home screen.




2 Press COLOR/IMAGE QUALITY.



3 Press COLOR SELECTION.



- **4** Choose the scanning mode.
- 5 Confirm with ok.



### Further settings



1 Press SEND on the Home screen.



2 Press QUICK SETUP.



Choose an item to be changed. After changing confirm with **o**K.

To enter a file name press **ADVANCED SETUP**. Press FILE NAME ENTRY and change the name. Confirm with **OK**.

3 Press **DESTINATION** to return.



## Fax operation

### Sending a fax

• Place the originals on the platen or in the optional document processor.



2 Press FAX on the Home screen.



3 Enter the destination address.



### From the address book:

Press ADDRESS BOOK. Press the checkbox to select the desired destination from the list. Press SEARCH (NAME) to find the destination. Enter the name you search for. Confirm with OK.

You may choose multiple destinations.

### **Enter the destination:**

Press FAX NO. ENTRY. Enter the fax number with the TEN-KEY pad. After that press OK.

If you want to send the fax to several destinations, go back to step 3.

**4** To send the fax press **START**.








# Cancelling fax job



- 1 Press STATUS/JOB CANCEL.
- 2 Press **SENDING JOBS**.
- 3 Choose the job to be cancelled and press CANCEL.
- **4** Confirm with **YES**.

Communication is cancelled.




### Check transmision result



- 1 Press STATUS/JOB CANCEL.
- 2 Press **SENDING JOBS**.
- **3** Under Job Type, select **FAX**.
- 4 Press LOG.
- 5 Select a job to be checked.
- 6 Press **DETAIL**.

The details are displayed.



# **Quick Guide 7057i/8057i**


# Print operation


### **Private printing**

**Note**: To activate the private printing from the PC, select the **JOB** tab in the printer driver and click **PRIVATE PRINT**. Protect your print job with a 4-digit access code if needed. The section **CUSTOM** allows you to type in your name directly.

- 1 Press JOB BOX on the Home screen.
- Select the creator of the private print job.
  - 3 Select the document to be printed from the list. If the document is password protected, type in the PIN with the TEN-KEY pad.
  - 4 Press PRINT to start printing.

**Note**: By pressing **DELETE** jobs can be cancelled.





# Media type settings

- When printing from an application press **PROPERTIES** button.
- 2 Choose BASIC tab.
- **3** To print on the special paper such as thick paper or transparency, click the **MEDIA TYPE** menu and select the media type.
- 4 Confirm with oK.



# Cancel print job



- Press STATUS/JOB CANCEL.
- 2 Press PRINTING JOBS.
- **3** Choose the job to be cancelled and press **CANCEL**.
- 4 Confirm with YES.

Job is cancelled.



# Copy operation

### Preparation

• Place the originals on the platen or in the optional document processor.



- 2 Press COPY on the Home screen.
- 3 Enter the number of copies with the TEN-KEY pad.



- 4 Choose PAPER SELECTION, DUPLEX, ZOOM, COMBINE, DENSITY or STAPLE/PUNCH (optional) in the sub menu from the main screen.
- **5** Confirm all settings with **OK**.
- **6** Press **START**.

### **Optional functions:**

The image quality settings can be changed.

- Press IMAGE QUALITY.
- **3** Choose **DENSITY**, **BACKGROUND DENSITY ADJ.**, **SHARPNESS**, **PREVENT BLEED-THRU** in the sub menu from the main screen.
- Onfirm all settings with ok.



